




Installation, Operation, & Maintenance Manual



RPSLinkIN

(9920-00092)

Modular Energy Storage System for Indoor Installations

Revision D: *Released 30-APR-2026*

Contents

Contents	2
1. Notice	6
2. Safety	8
2.1 Warnings, Cautions, and Important Notes	8
2.2 Battery Precautions	10
2.3 Disposal and Recycling	11
3. Emergency Response Plan	12
3.1 Emergency Response Considerations for Indoor Fixed Installation	13
4. System Overview	18
4.1 RPSLinkIN Overview	18
4.1.1 RPSLink Configuration Naming Convention	18
4.2 Fail-Safe Anti-Propagation Technology	18
4.3 Physical Parameters	19
4.3.1 RPS50 Battery Pack Dimensions	19
4.3.2 PCS Cabinet Dimensions	20
4.3.3 IP Ratings	20
4.4 Specification Table	21
4.5 PCS Cabinet Components	22
4.6 Example RPSLinkIN 1-line Diagrams	25
4.6.1 Example 1: 150kWh On-Grid BESS	25
4.6.2 Example 2: 150kWh On / Off-grid BESS	26
4.6.3 Example 3: 600kWh On / Off-Grid BESS	27
4.7 RPSLinkIN Certifications	27
5. ViSTA® Cloud	28
5.1 Logging In	28
5.1.1 Email Notification	28
5.2 ViSTA® Dashboard	29
5.2.1 Fleet View	29
5.2.2 Unit View	30



5.2.3	Alarm View.....	31
5.2.4	Time Window	32
6.	Installation.....	34
6.1	Location Considerations	34
6.1.1	Room/Area Specific Considerations.....	34
6.2	EMI/EMC Considerations	35
6.2.1	Definitions	35
6.3	Handling and Transport.....	36
6.3.1	General Considerations	36
6.3.2	Loading and Unloading	37
6.4	Wiring Install Instructions.....	38
6.4.1	Sinexcel Intelligent Transfer Switch	38
6.5	Commissioning	39
6.5.1	Introduction	39
6.5.2	RPSLinkIN Commissioning Checklist	39
7.	Startup	42
7.1	RPSLinkIN General Startup Instructions	42
7.2	RPSLinkIN Advanced Settings.....	45
8.	SHUT DOWN.....	47
8.1	RPSLinkIN Shutdown Instructions.....	47
9.	Maintenance	49
9.1	Periodic Scheduled Maintenance	49
9.1.1	Sinexcel Inverter	50
9.1.2	PCS Cabinet.....	50
9.1.3	General Electrical and Bolt Interface Connections	50
9.1.4	Energy Management System (EMS) Cabinet(s)	50
9.1.5	Torque Check	50
9.1.6	Torque Check Table	51
9.1.7	Torque Reference Images	51
9.2	Decommissioning	52
9.3	ViSTA® Alarm Definition Glossary	53

9.4 ViSTA® Alarms 54

9.5 Contact Viridi Customer Service 59



1. Notice

As an express condition of Viridi's warranty and to encourage utilization of industry best practices, Viridi requires that the installation, mobilization, and operation of the RPSLinkIN only be completed by, or at the direction of, a qualified professional as defined by the jurisdiction(s) within which the installation, mobilization, and operation occurs. Specific applications can vary, so please direct specific questions to Viridi's attention:

- **Customer Service, Parts and Warranty: 1-800-984-7434**
- **Parts Ordering: parts@viridiparente.com**
- **Service Issues: service@viridiparente.com**
- **Warranty Claims: warranties@viridiparente.com**
- **Sales: 1-716-968-8658; email: sales@viridiparente.com**
- **Service: 1-866-984-7434; email: service@viridiparente.com**

Viridi expressly disclaims liability for applications made in a manner inconsistent with this guide and/or in non-compliance with local building and electrical codes. This Installation, Operations & Maintenance Manual, incorporates all terms and conditions of sale. All information provided in this manual is subject to change with or without notice.

Please refer to the warranty documents provided at the point of sale for further information.



SAFETY



2. Safety

To make the best and proper use of the RPSLinkIN, all personnel handling or operating the RPSLinkIN are advised to follow these guidelines:

- Only fully trained and qualified personnel should operate or service the machine. Read and understand the Installation, Operations & Maintenance Manual before operating the equipment to make certain that safe practices are followed, including service and maintenance intervals.
- If there is a defect or evidence of damage that might expose an employee to injury, the defective or damaged RPSLinkIN shall be removed from service, and no employee may use it until repairs and tests needed to render the equipment safe have been made.
- Always keep this Installation, Operations & Maintenance Manual in a convenient place for easy access.
- If this Installation, Operations & Maintenance Manual, is lost or damaged, contact Viridi Customer Service, referencing the equipment serial or asset number.
- This Installation, Operations & Maintenance Manual should be considered part of the RPSLinkIN and remain with it.
- Constant efforts are made to improve the quality and performance of our products; it may be that some information in the User Manual differs from your equipment. If any questions arise, please contact Viridi Parente, Inc.
- All the information in this publication is based on the latest product information available at the time of printing. Viridi Parente, Inc. reserves the right to make changes to this Installation, Operations & Maintenance Manual, without notice or obligation.
- No part of this publication may be reproduced or copied without prior written permission from Viridi Parente, Inc.

2.1 Warnings, Cautions, and Important Notes









This “Safety Alert” symbol and others like it are in place to warn the operator of potential hazards. It means attention/become alert – the operator’s safety is involved!

This symbol can signify DANGER and, where used, documents a WARNING or CAUTION which is followed by text highlighting the potential hazard. This manual will detail the potential hazards so that necessary precaution(s) towards ensuring operator and equipment safety.

A **WARNING** signifies a situation whereby the operator, members of staff, or the public could be put in danger of personal injury by the improper operation of the RPSLinkIN.

A **CAUTION** signifies a situation whereby damage to the RPSLinkIN or associated parts could be caused by improper operation of the RPSLinkIN.

Symbols Used in This Manual

	Warning/Cautions		Wear Gloves
	Shock Hazard		Quality
	General Safety		Tip

General Precautions



COMPETENT PERSONNEL: The RPSLinkIN is intended for use by suitable qualified, trained, and competent personnel who have read and understood this manual and are familiar with the equipment and its intended use. A certain level of user competence is assumed when operating power generating equipment.



READ AND UNDERSTAND: Before personnel operate, service, or perform tasks on the equipment, the manual must be read and understood.



VENTILATION: Do not obstruct the air vents and allow adequate space around the RPSLinkIN for ventilation.



ELECTRICAL SAFETY: Follow all applicable electrical codes and standards. Ensure proper grounding and bonding of the system components. Use appropriate PPE, including high voltage gloves, safety glasses, protective clothing, and insulated tools when working on electrical connections.



PRECAUTIONS: Follow the precautions listed within this manual before operation and during operation, service, and maintenance activities for the safety of the operator and others and to protect the performance of the equipment.



WARNING LABELS: Keep warning and caution labels from becoming dirty or torn and replace them if they become damaged. Replacements can be obtained by contacting Viridi Parente, Inc.



SAFETY: Safety is an utmost concern. Safety statements are one of the primary ways to call attention to potential hazards associated with generator operations.



FIRE SAFETY: Install fire suppression systems as required by local codes and regulations. Ensure that fire extinguishers and other firefighting equipment are readily accessible and properly maintained.



EMERGENCY PROCEDURES: Establish and communicate emergency procedures, including shutdown protocols, evacuation routes, and first responder action plans. Ensure that all personnel are trained in these procedures.

Cautions and Warnings



CRUSH HAZARD: The RPSLinkIN is a crush hazard when elevated above ground level, and the area below the RPSLinkIN should be cleared before hoisting the RPSLinkIN above ground level.



DANGER OF FALLING: Do not stand on top of the RPSLinkIN. The surface may be slippery.



HEAVY ITEM: The RPSLinkIN is heavy; care must be taken when handling the unit to avoid injury.
















To prevent the risk of electric shock, Arc Flash, or equipment damage, ensure that the system is completely de-energized, and all power sources are fully disconnected before performing any internal maintenance on the Battery Energy Storage System (BESS). This includes:



- Confirming that the key switch and 24v disconnect are in the **OFF** position.
- Ensuring that all breakers, including those on the BESS system and common bus (if applicable), are in the **open (OFF)** position.
- Verify that all incoming and outgoing power sources are disconnected/unplugged.



SHOCK HAZARD: Authorized access only. Do not remove panels to access internal components of the RPSLinkIN. There are no user-serviceable parts inside the RPSLinkIN. Only qualified, competent personnel are permitted to service internal components. Unauthorized Persons attempting to do so will be at risk of electric shock.

	SITE ACCESS: Restrict access to the installation site to authorized personnel only. Implement security measures such as fencing, surveillance, and access control systems to prevent unauthorized entry
	Do not allow cable connections or the RPSLinkIN to lie in or under water
	Do not apply tension to or overtighten connectors
	Do not make or break connections while the RPSLinkIN is carrying a load
	The RPSLinkIN has a maximum power capacity of 30 KW. Do not attempt to exceed the stated maximum power capacity.
	The RPS150's Dielectric Withstand Test Voltage is 1960Vac
	HIGH VOLTAGE: The battery energy storage system contains high voltage components. Always de-energize the system before performing any maintenance or repairs. Use lockout/tagout procedures to ensure the system remains de-energized during work.
	THERMAL RUNAWAY: Be aware of the risks associated with thermal runaway in lithium-ion batteries. Implement measures to detect and mitigate thermal runaway events, such as temperature monitoring and automatic shutdown systems.
	CHEMICAL HAZARDS: Batteries contain hazardous chemicals that can pose health risks if released. In the event of a battery leak or spill, follow appropriate hazardous material handling procedures and use spill containment equipment.
	MECHANICAL HAZARDS: Use proper lifting techniques and equipment when handling heavy battery packs. Ensure that battery packs are securely mounted and supported to prevent tipping or falling.
	All areas containing ESS shall provide proper egress from the area in accordance with the local building codes
	Fire control and suppression is required for rooms or areas containing ESS, unless modified by applicable code or AHJ approval.
	System Alarms and annunciation for the installation shall comply with applicable fire codes
	Additional fire protection is managed through the RPSLinkIN telecom device and ViSTA notification system. This system is programmed to send notifications to authorized users in the event of any abnormal functioning or temperature deviation so that immediate appropriate action can be taken. It is recommended that all Viridi BESS be operated with the ViSTA notification system.
	Areas containing the ESS shall be provided with smoke detection or radiant energy-sensing systems unless modified by code or approved by the AHJ. The systems shall comply with applicable fire codes

2.2 Battery Precautions

The chemicals and materials in the battery are stored in a sealed container, designed to withstand temperatures and pressures encountered during normal use. As a result, during normal use, there is no physical danger of ignition, explosion, or hazardous material leakage. There is only a risk of exposure if a battery is mechanically, thermally, or electrically abused. There is no user access to the batteries. Do not remove panels. For the RPSLinkIN to operate at an optimal capacity, they should be stored in a cool, dry place away from direct sunlight and sources of heat.

2.3 Disposal and Recycling

The RPSLinkIN comprises components that must be disposed of responsibly. Many of the components can be reused or recycled. For advice on the safe and proper disposal of RPSLinkIN, please contact the Viridi sales representative. Viridi Parente, Inc. partners with American Battery Technology Company to disassemble end of life battery cells into critical minerals to be reused.

3. Emergency Response Plan

The RPSLinkIN includes internal fault mechanisms designed to prevent failures and subsequent risk hazards. However, Viridi cannot guarantee safety performance of the RPSLinkIN if the equipment is exposed to abuse, damage, or negligence.

If an installer or user happens to be exposed to the internal materials of the battery cell due to damage on the outer casing, the following actions are recommended:

- **In Case of Inhalation:** Leave the contaminated area immediately and seek medical attention.
- **In Case of Skin Contact:** Wash the contacted area thoroughly with soap and seek medical attention.
- **In Case of Ingestion:** Seek immediate medical attention.

If a fire breaks out at or near the location of the RPSLinkIN, perform the following counter measures:

- In the event of a fire, appropriate extinguishing media should be used based on the type of incident. For battery-related fires, the system should be allowed to burn itself out while defensive firefighting strategies are employed to protect nearby exposures, if necessary. For non-battery-related fires, such as those occurring near an RPSLinkIN unit, suitable extinguishing agents, including water or an ABC fire extinguisher, should be utilized. Additionally, if a fire occurs adjacent to the RPSLinkIN, water may be applied as a defensive measure to cool the unit, if deemed necessary.
- Building occupants shall evacuate the building immediately upon discovery of fire, call local emergency services
- Follow the proper firefighting instructions. If a fire occurs when charging the RPSLinkIN, press the E-STOP, then provided it is safe to do so, disconnect the battery pack circuit breaker. If the battery pack is not on fire yet, extinguish the fire before the battery pack catches fire, preferably with water. If the battery pack within the RPSLinkIN is on fire, do not try to extinguish it, and evacuate people from the premises immediately.
- **WARNING:** Explosion is possible if the battery pack within the RPSLinkIN experiences temperatures above 150°C (302°F). When a battery pack is burning, it will leak poisonous gases. Do not approach it.
- To deal with an accident with the RPSLinkIN on land, refer to the site-specific emergency response plan, if available and move the damaged RPSLinkIN to a segregated location and call your local fire department or service engineer. Service inspection must be completed by Viridi or an authorized service center before the unit can be cleared for operation.
- Note that proper lockout/tagout procedures must be followed in such cases. To deal with an accident with the RPSLinkIN in the water, stay out of the water and do not touch anything if any part of the battery, inverter, or wiring is submerged. Do not use the submerged battery again.
 - Contact your Viridi Service Team for assistance at:
 - Customer Service Line: 1-866-984-7434
 - Email: service@viridiparente.com

3.1 Emergency Response Considerations for Indoor Fixed Installation

The RPSLinkIN is a modular lithium-ion Battery Energy Storage System (BESS) designed for fixed indoor installation in residential, commercial, and industrial buildings. The system has been tested per UL 9540A Edition 5 under residential, indoor, floor-mounted conditions and met all five performance requirements of that standard, including zero detectable release of flammable or toxic gas during unit-level testing.

The following representative scenarios are provided to demonstrate how emergency response considerations may vary by context, while maintaining consistent hazard controls, system safeguards, and coordination with emergency responders.

These scenarios are illustrative only and do not replace the authority or operational discretion of the Fire Department. In all cases, emergency response actions shall align with Section 3 of this Emergency Response Plan and applicable codes and standards.

➤ **Scenario A: Thermal Event During Normal Operation - Unoccupied Mechanical or Utility Space**

- **Description** - The RPSLinkIN is installed in a dedicated utility or mechanical room within a residential, commercial, or industrial building. The system is operating normally in charging, discharging, or standby mode when an abnormal thermal condition is detected. The space is unoccupied at the time of initial detection, and the event is identified through both a ViSTA Cloud remote monitoring, control, and alarm notification and by building occupants observing an alarm state on the DEIF IE250 HMI on the front face of the PCS Assembly.
- **Primary Considerations**
 - Fixed indoor installation in a confined or semi-confined space
 - Potential for limited egress from the installation room
 - System may will be in an active fault or alarm state upon responder arrival
 - BMS may will have already initiated automatic de-energization of the battery pack prior to responder arrival, either through detection of a cell-level fault or upon pack temperature exceeding 45°C (113°F)
- **Emergency Response Considerations**
 - Upon detection of an abnormal condition, building occupants shall evacuate the immediate area and call emergency services. The ViSTA Cloud monitoring platform may have already generated a remote alarm visible to the building operator or Viridi's service team.
 - Upon arrival, emergency responders shall be informed that the RPSLinkIN is a fixed lithium-ion NMC battery energy storage system and that high voltage DC and AC components are present.
 - The external emergency stop (E-stop) is located on the front face of the PCS Cabinet, above the DEIF IE250 HMI. If deemed safe and appropriate by responding personnel, the E-stop may be activated to electrically isolate the system without opening the enclosure.
 - Responders should be aware that the RPSLinkIN's BMS is designed to automatically open the main contactors and de-energize the battery pack upon detection of a cell-level fault or if pack temperature exceeds 45°C (113°F), and either action may have already occurred prior to arrival.
 - The RPSLinkIN has been tested per UL 9540A Edition 5 under residential, indoor, floor-mounted conditions and met all five performance requirements of that standard, including zero detectable release of flammable or toxic gas. Firefighting response shall nonetheless follow a defensive strategy consistent with the general Emergency Response Plan, with priority given to life safety and responder safety.
 - If no fire is present the system shall remain out of service until inspected and cleared by Viridi or an authorized service center.
 - Firefighting tactics, evacuation distances, and scene control remain at the discretion of the responding fire department.



➤ **Scenario B: Fire External to the BESS Within the Same Space**

○ **Description**

A fire originates from a source other than the RPSLinkIN — such as an adjacent electrical panel, HVAC equipment, stored materials, or building structure — within the same room or immediately adjacent space as the installed RPSLinkIN. The system is not the origin of the fire but is present as an energized high-voltage system in the affected area.

○ **Primary Considerations**

- The RPSLinkIN is not the fire origin but represents an energized system within the fire environment
- Thermal exposure from an external fire may affect the BESS enclosure
- Responder decision-making regarding suppression tactics must account for the presence of the energized BESS
- Building occupancy type may vary — residential, commercial, or industrial
- BMS may have already initiated automatic de-energization of the battery pack prior to responder arrival upon internal pack temperature exceeding 45°C (113°F).

○ **Emergency Response Considerations**

- Building occupants shall evacuate the building immediately upon discovery of fire and call emergency services.
- Upon arrival, emergency responders shall be informed of the presence of a fixed lithium-ion NMC BESS in or adjacent to the fire area and that the system may be energized.
- For the non-battery fire, suitable extinguishing agents including water or an ABC fire extinguisher may be used. Water may additionally be applied to the exterior of the RPSLinkIN enclosure as a defensive cooling measure if deemed necessary by the responding fire department, in order to limit heat transfer to the battery system.
- The ¼" steel IP55-rated enclosure of each RPS50 Battery Pack provides a durable barrier against external thermal exposure.
- Responders should be aware that the BMS within the RPSLinkIN's is designed to automatically de-energize the battery pack upon detection of a cell-level fault. Additionally, the BMS will automatically open the main battery contactors and de-energize the pack if the pack temperature exceeds 45°C (113°F). In an external fire scenario, this thermal threshold would be reached prior to or independent of any cell-level fault condition, providing an additional layer of automatic isolation as the thermal environment escalates.
- If deemed necessary, safe and appropriate, the E-stop located on the front face of the PCS Assembly, above the HMI may be activated to electrically isolate the system. If fire conditions prevent safe access to the E-stop, isolation shall not be attempted manually. Rather, it shall be done through the ViSTA Cloud system. Note this is NOT necessary if the BMS has already de-energized the pack automatically, which can be determined through the ViSTA Cloud notification system.
- The RPSLinkIN has been tested per UL 9540A Edition 5 under residential, indoor, floor-mounted conditions and demonstrated zero detectable release of flammable or toxic gas under thermal stress conditions. This performance characteristic is relevant to responder safety assessments when the BESS is exposed to an external fire environment.
- Firefighting tactics, suppression decisions, evacuation distances, and scene control remain at the discretion of the responding fire department.

➤ **Scenario C: Occupied Building — First Responder Arrival with System in Fault or Alarm State**

○ **Description**

The RPSLinkIN is installed in a residential, commercial, or industrial building that is occupied at the time of an incident. A fault or alarm condition has been triggered — detected either through the DEIF IE250 HMI on the PCS Assembly, a ViSTA Cloud remote monitoring, control, and alarm notification, or a building fire alarm integration — and emergency responders arrive to a building with occupants present and the BESS in an active alarm or fault state. No visible fire may be present at the time of arrival.

○ **Primary Considerations**

- Building is occupied; life safety and occupant coordination are the primary priorities
- System is in a fault or alarm state but may not have progressed to a fire condition
- Responders must assess an energized high-voltage system without the benefit of visible indicators of fire
- Remote monitoring data may be available through the building operator or Viridi's service team to inform responder situational awareness

○ **Emergency Response Considerations**

- Building occupants shall be evacuated or sheltered in place at the direction of emergency responders, consistent with applicable life safety codes and the authority of the responding fire department.
- Upon arrival, emergency responders shall be informed that the RPSLinkIN is a fixed lithium-ion NMC BESS in an alarm or fault state, that high voltage DC and AC components are present, and that the BMS may have already initiated automatic isolation of the battery pack — either through detection of a cell-level fault or upon internal battery pack temperature exceeding 45°C (113°F).
- The E-stop is located on the front face of the PCS Assembly, above the DEIF IE250 HMI. If responders determine it is safe and appropriate to do so, the E-stop may be activated to electrically isolate the system without opening the enclosure.
- The ViSTA Cloud control, monitoring, alarm platform provides remote visibility into system alarm status and severity. Building operators or Viridi's service team (1-866-984-7434 / service@viridiparente.com) may be able to provide responders with real-time system status information to support situational awareness.
- In the absence of visible fire, responders should treat the area around the RPSLinkIN as a potential hazard zone and avoid opening enclosures or attempting internal access. There are no user-serviceable components inside the RPSLinkIN.
- The RPSLinkIN has been tested per UL 9540A Edition 5 under residential, indoor, floor-mounted conditions and met all five performance requirements of that standard, including zero detectable release of flammable or toxic gas. Responders should nonetheless approach any BESS fault condition with appropriate caution until the nature of the fault is determined.
- The system shall remain out of service following any fault event until inspected and cleared by Viridi.
- Evacuation decisions, hazard zone establishment, and all scene control remain at the authority of the responding fire department.

➤ **General Notes Applicable to All Scenarios**

- Emergency response actions shall always prioritize life safety and responder safety above all other considerations.
- The ViSTA remote control, monitoring, and alarm system can be accessed by Viridi owners, building owners, and first responders to determine the state of the system, and whether it is energized or not. This can be done prior to entering rooms where packs are located during an emergency response situation.



- The RPSLinkIN is a fixed, floor-mounted system and shall not be moved or relocated during or following an incident without direction from Viridi or an authorized service center.
- Firefighting tactics, evacuation distances, suppression decisions, and scene control remain at the sole discretion of the responding fire department.
- The E-stop located on the front face of the PCS Assembly above the DEIF IE250 HMI, provides a means of electrical isolation accessible without opening any enclosure. Activation does not substitute for full lockout/tagout procedures, which must be performed by qualified personnel prior to any post-incident inspection or service activity.
- This scenario-based guidance is intended to supplement, not replace, site-specific emergency response planning where such plans are available and required by the authority having jurisdiction (AHJ).

➤ **Contact Viridi Customer Service for emergency support: 1-866-984-7434 | service@viridiparente.com**

SYSTEM OVERVIEW



4. System Overview

Disclaimer: The images contained within this section and the ensuing sections may not be directly reflective of a complete installation. Custom installation solutions are possible depending on space constraints of the installation location.

4.1 RPSLinkIN Overview


The RPSLinkIN is a modular Lithium-Ion Battery Energy Storage System for indoor installation in residential, commercial and industrial buildings. It is designed to scale in increments of roughly 50kWh to fit the spacing and energy requirements of nearly any application. It consists of two major components:

RPS50 Battery Pack – the 50kWh building block allowing a system to be designed from 50kWh to multiple Megawatt hours

PCS Cabinet – containing the system’s inverter, power electronics, and VCom IoT edge computer

4.1.1 RPSLink Configuration Naming Convention

RPSLinkIN-480V-3p-150kWh-30kW



EX: BESS equipment is skid mounted within a NEMA rated enclosure for outdoor installations on a concrete pad

IN: BESS equipment components are individually skid mounted for indoor installations



4.2 Fail-Safe Anti-Propagation Technology

Viridi’s core value proposition lies in the Fail-Safe Anti-Propagation architecture built into RPS50 battery packs, each of which contains 48.9kWh of nameplate energy storage. UL9540A testing, which involves intentionally heating a cell within the pack to the point of thermal failure, demonstrated that Viridi’s passive technology halts cell-to-cell thermal propagation with no detectable release of heat, sparks, smoke, or flames. The pack enclosure is built from ¼” steel and IP55 rated for an extremely durable industrial design built to survive harsh environments. This technology makes Viridi’s BESS uniquely suitable for safe deployments in and around occupied spaces and critical equipment.


4.3 Physical Parameters

RPSLinkIN is a modular system built from two major components: RPS50 Battery Pack and PCS Cabinet.

4.3.1 RPS50 Battery Pack Dimensions



4.3.2 PCS Cabinet Dimensions



4.3.3 IP Ratings

RPS50 battery pack carries an IP55 rating

4.4 Specification Table

Model	480V-3p-300kWh-60kW	480V-3p-150kWh-30kW	480V-3p-100kWh-20kW	480V-3p-50kWh-10kW
System Contains	(1) PCS Cabinet	(1) PCS Cabinet	(1) PCS Cabinet	(1) PCS Cabinet
	(6) RPS50 Packs	(3) RPS50 Packs	(2) RPS50 Packs	(1) RPS50 Packs
Nameplate Capacity (kWh)	293.4	146.7	97.8	48.9
Usable Capacity (kWh)	260.4	130.2	86.8	43.1
Max Continuous Power, Charge/Discharge (kW)	60	30	20	10
Operating Voltage	480VAC 3Φ			
Max Continuous Current, Charging/Discharging (A)	72.2	36.1	24.1	12.0
Onboard Inverters	(2) Sinexcel PWS2-30P-NA	(1) Sinexcel PWS2-30P-NA	(1) Sinexcel PWS2-30P-NA	(1) Sinexcel PWS2-30P-NA
PWS2-30P-NA Fault Current Contribution [AC side short circuit current on-grid] (A)	260A / 100 MS	130A / 100 MS	130A / 100 MS	130A / 100 MS
Maximum Overcurrent Protection Device Rating (A)	125A	60A	40A	20A
Allowed Conductor Type & Size Range	Cu/Al	Cu/Al	Cu/Al	Cu/Al
	2-8 AWG	2-8 AWG	2-8 AWG	2-8 AWG
	Cu/Al (Str)	Cu/Al (Str)	Cu/Al (Str)	Cu/Al (Str)
	2/0 -1 AWG	2/0 -1 AWG	2/0 -1 AWG	2/0 -1 AWG
Recommended Conductor Sizing	1 AWG	6 AWG	6 AWG	6 AWG
Grounding Requirements	Grounding must comply with local code requirements			
Auxiliary Power Requirements	RPSLinkIN is an autonomous unit requiring no aux power fed from outside BESS cabinet			
Operating Temp. Range	-14°F to 113°F / -10°C to ~45°C ¹			
Cycle Life	4,000+ charge / discharge cycles ²			
Communication / Telematics	BESS uses WIFI / LAN / 5G / LTE to report EMS and performance data to Viridi ViSTA®.			
	RPSLink typically communicates to ViSTA® via LAN or WIFI.			
Backup Power	An optional Sinexcel Intelligent Transfer Switch is required for RPSLink to provide resilient power during a grid outage			


¹ Operating temperature range mirrors battery cell specifications. The Battery Management System (BMS) is programmed to manage the pack utilization rate to control the internal pack thermal conditions and prevent operation outside of pack interior temperature limits, which can be tailored for different applications/ installations. The BMS communicates applicable operating conditions continuously via CAN bus to the inverter and/or system controller.

² Cycle life can be optimized for individual applications and operating conditions (depth of discharge, duty cycle, temperature, charge/discharge rate).




4.5 PCS Cabinet Components

PCS Assembly




PCS Assembly Assess
(Panels Removed)



System Diagrams

Note: below is the Schematic for the 480V 3P version of the RPSLinkIN, if another version is needed, it is also available via request to Viridi.




4.6 Example RPSLinkIN 1-line Diagrams

RPSLinkIN is a modular system that can be designed into many configurations – the following 1-line diagrams represent a few typical arrangements but are by no means representative of every system. Please contact Viridi’s Technical Sales Department at 716-968-8658 for configuration assistance.


4.6.1 Example 1: 150kWh On-Grid BESS

[Behind The Meter] 208VAC 3Φ Solar PV + RPSLinkIN-480V-3p-150kWh-30kW




4.6.2 Example 2: 150kWh On / Off-grid BESS

[Behind The Meter] 480VAC 3Φ Solar PV + RPSLinkIN-480V-3p-150kWh-30kW + PWD-100M (for off-grid backup) + EMS



4.6.3 Example 3: 600kWh On / Off-Grid BESS

[Behind The Meter] 480VAC 3Φ Solar PV + (4) RPSLinkIN-480V-3p-150kWh-30kW + PWD-100M (for off-grid backup) + EMS



4.7 RPSLinkIN Certifications

- UN 38.3 (cell, module)
- UL 1642 (cell) UL Recognized Component
- UL 1741 (Sinexcel PWS2-30P-NA inverter) cTÜV SÜDus Listed
- UL 1741 (Sinexcel PWD-100M & PWD300M Transfer Switches) cETLus Listed
- IEEE 1547 (inverter) cTÜV SÜDus Listed
- UL 1973 (pack) cTÜVus Listed
- UL 2580 (cell) UL Recognized Component
- UL9540 (ESS) cTÜVus Listed
- UL 9540A (cell/module/pack tested)
- NFPA 855, Standard for the Installation of Stationary Energy Storage Systems

5. ViSTA® Cloud

RPSLink utilizes a wireless cellular communications module to send location and usage metrics to an administrative dashboard called ViSTA Cloud. The following will provide the basics for utilizing ViSTA®.

5.1 Logging In

Request a ViSTA® Cloud account by emailing service@viridiparente.com.


An email will be sent from: vista.notifications@viridiparente.com with a link to setup the account.

Once setup, login by going to: <https://vista.viridiparente.com/login>.

5.1.1 Email Notification

Follow the link or QR Code below to submit the Viridi ViSTA® User Request Form. Requests can be submitted for BESS Alert Notifications and Basic Vista User Account.

Viridi ViSTA® User Request Form à <https://forms.office.com/r/mjH2FQr9DR?origin=lprLink>




For additional assistance, questions, or custom requests, please contact Viridi Service at:

Phone: 1-866-984-7434

Email: service@viridiparente.com.


5.2 ViSTA® Dashboard

5.2.1 Fleet View



1. **Alarms:** This button opens a modal for viewing alarms, which can be filtered to show any alarms notifications status and severity.
2. **Notes:** This button allows the user to update notes for the unit.

5.2.2 Unit View



1. **Select Unit:** By Clicking on the row, you will select a unit
2. **Selected Unit:** This tells you which unit is currently selected
3. **Time Window:** This allows you to modify the time window. See section 5.2.4 (Time Window) for more information.
4. **Connectivity:** This allows you to view the connectivity statistics of the selected unit.
5. **Ping Sensor:** this allows you to ping the VCom and sensors to test connectivity.

5.2.3 Alarm View

The alarms area permits viewing of active alarms, the type of alarm, the severity, and the status of the alarm on RPSLink.

<input type="checkbox"/>	Created time ↓	Type	Severity	Status			
<input type="checkbox"/>	2025-06-09 16:07:21	Skid 8 High Voltage Isolation	Minor	Active Unacknowledged			
<input type="checkbox"/>	2025-06-09 16:07:21	Skid 7 High Voltage Isolation	Minor	Active Unacknowledged			
<input type="checkbox"/>	2025-06-09	Skid 8 High		Cleared			

Items per page: 10 1 - 10 of 17

Clicking on the box to the left of the alarm will acknowledge and/or clear the alarm.

Note: The alarm is only cleared on ViSTA®, not on the RPSLink

Clicking on the word bubble icon on the right will allow a screen view to see the activity of the RPSLink add comments concerning the alarm.


5.2.4 Time Window

By clicking the clock icon in the upper right-hand corner of any of the diagram or system devices screens will open a menu will allow viewing the real time activity or history of the system.

The real time tab allows you to choose a period to view from the current time to however long ago it is set for.

The History tab is the same as the real-time tab except for the ability to choose a period in the past to view instead of just allowing a view of what the system is doing for an ongoing time frame. For example, the selection can permit a view: a day from three weeks ago instead of the past 24 hours.

It is recommended when working with a time window larger than 1-day that the aggregation method is set to "Average".



INSTALLATION



6. Installation

6.1 Location Considerations

Determine the necessary size of energy storage/back-up system for your specific application. Different project sites require different kWh of energy storage.



Submit designs and plans to appropriate authorities for review. Before beginning installation or utilization, permits and inspections must be obtained in accordance with local laws and regulations, as necessary



Coordinate site delivery and installation. RPSLinkIN components are heavy and must be installed with proper equipment. RPSLinkIN must be installed according to the design plans above.



Combustible Material shall not be stored within 3 ft (0.91m) of the RPSLinkIN

To decommission or uninstall the RPSLinkIN, contact your Viridi service team for further instruction. This must be completed by Qualified Personnel, and any disposal of components requires compliance with local laws, rules, and regulations. Viridi encourages recycling of all materials where possible and works with American Battery Technology Company to recover lithium-ion battery components

Required equipment, tools, and other items depend on the final consumer and installation location. Consult your service engineer and local installer for further instruction.

6.1.1 Room/Area Specific Considerations

The following shall be considered when identifying an area and/or location to house the RPSLinkIN

- Rooms containing the ESS shall have signage, per NFPA 855, installed on the front doors or in approved locations.
- The Signs shall contain:
 - 'Energy Storage Systems' with symbol of lightning bolt in a triangle
 - Type of Technology associated with the ESS
 - Any special hazards as identified in NFPA 855
 - Type of suppression system installed in the area of the ESS
 - Emergency Contact information
- Any guard post installed at the location shall be at least 3ft (0.91m) from the ESS.
- ESS shall be secured against unauthorized entry.
- ESS shall always be located on floors that can be accessed by external fire departments
- If the RPSLinkIN is installed below building grade:
 - It shall be approved by the local Authority Having Jurisdiction (AHJ).
 - The ESS shall not be located inside an electrical room.
 - ESS shall be accessible to emergency responders without traversing through an electrical room.
- Rooms or spaces containing ESS shall be separated from other areas of the building by fire barriers with a minimum 2-hour fire resistance rating and horizontal assemblies with a minimum 2-hour fire resistance rating and constructed in accordance with the local building code unless otherwise modified by applicable codes or Authority Having Jurisdiction (AHJ).
- ESS installed in dedicated-use building shall comply with applicable fire codes.

6.2 EMI/EMC Considerations
















6.2.1 Definitions

Electromagnetic interference (EMI) and electromagnetic compatibility (EMC) are both important considerations when working with electronic components. EMI is caused by electromagnetic emissions that can disrupt the function of electronic devices and radio frequency (RF) systems. These devices and systems must be properly shielded from electromagnetic radiation for them to work well. EMC measures how well these devices and systems can work in the presence of disruptive electromagnetic interference. Additionally:

- The inverter UL lists safety standards for the Inverter 1741 Supplement B and the Battery UL 1973 (pack) cTÜVus Listed recognition standards.
- The inverter and battery undergo EMI/EMC testing.
- The BESS undergoes ground bond testing to verify low chassis/earth impedance on the ground lug in the EBox.
- Within RPSLinkIN, all communication wiring if run near high voltage AC/DC wiring is shielded to reduce the potential effect. Otherwise, it is run in separate locations to remove the EMC/EMI potential on the communication lines.


6.3 Handling and Transport

6.3.1 General Considerations

	Do not expose RPSLinkIN components to an open flame.
	Do not place or store RPSLinkIN components near highly flammable materials.
	Do not expose or place RPSLinkIN components near water sources.
	Do not install RPSLinkIN components in an airtight enclosure or in an area without ventilation.
	Store RPSLinkIN components on a flat, level surface in a cool, dry location.
	Do not disconnect, disassemble, or repair RPSLinkIN components with unqualified personnel. Only Qualified Personnel should handle, install, and service the RPSLinkIN components.
	Do not deform, impact, cut, or penetrate the RPSLinkIN components with a sharp object. Doing so may cause a fire or leakage of electrolytes.
	Do not step on or stand on RPSLinkIN components or their packaging.
	Do not place any objects on top of RPSLinkIN components.
	Do not charge or discharge RPSLinkIN if damaged or malfunctioning.
	All units must be transported in compliance with 49 CFR 171-180, Pipeline and Hazardous Materials Safety Administration (PHMSA) Hazardous Materials Regulations, and UN38.3.
	Specific to ESS units transported within New York City, the movement of vehicles carrying hazardous materials is additionally subject to the New York City Fire Code (FC 2701–2707) and the New York City Department of Transportation (NYC DOT) Hazardous Materials Transportation Regulations
	Compliance includes but is not limited to: <ul style="list-style-type: none"> • Use of designated New York City hazmat routes. • Tunnel restrictions prohibiting most lithium battery shipments.
	<ul style="list-style-type: none"> • Required vehicle placarding per 49 CFR • No stopping/standing except in designated areas. • Driver HazMat endorsement and required training • Time-of-day restrictions, when applicable
	Upon receipt of the line, inspect the unit for any major damage that might have been incurred as part of the shipping process.
	If an RPSLinkIN battery within the link is damaged during transport the battery will be shut off by the main contactor and the battery will not turn ON. If this is the case, please contact Viridi for support.

6.3.2 Loading and Unloading

Note: Lifting and unpacking guidelines will depend on the final consumer and local installation parameters. Follow established workplace safety guidelines and procedures when receiving, handling, transporting, unpacking, lifting, and installing RPSLinkIN



Components. Loading and Unloading

6.4 Wiring Install Instructions

Step 1 — Ground of Batteries and Power skid & Electronics Box

- Run grounding wires between each battery in the string or strings
- Run ground wire from closest battery to the Power skid

Step 2 — Run High Voltage DC Cable

- Run HV DC cables between the string of batteries in series (Master, Remote 1, Remote 2)
 - Run the DC cables from the string of batteries to the inverter inside the Power Skid
 - Plug in all connectors into the Batteries and Inverter, verify with a push – pull – push method
 - Repeat for string 2 and inverter 2 if present.

Step 3 — Run Low Voltage Harness

- Run Low voltage / Communication harness between string of batteries and Electronic Box
- Make connections DT12 connections at the Electronics Box & Master Battery
- Make DT6 connections at Remote 1 and Remote 2 batteries if present
- Repeat for string 2 if present.

Step 4 — Run and Land utility connection AC wiring

- Drop Utility connection wiring into the RH side of the power skid (junction box)
- Land the 3-phase wire connections to the bottom of the 3-phase terminal block
- Land the Ground wire to the 1-Phase terminal block

6.4.1 Sinexcel Intelligent Transfer Switch

The Sinexcel PWD-100M / PWD-300M Intelligent Transfer Switch are optional components required for RPSLinkIN to provide automatic backup during a loss of grid power.

Step 5 — Utility and Load connections w/ Intelligent Transfer Switch

- Drop Utility connection wiring into housing for Intelligent transfer switch and land on the “GRID” Connection
- Drop Load connection wiring into housing for Intelligent transfer switch and land on the “LOAD” Connection
- Drop PCS connection wiring into housing for Intelligent transfer switch from the PCS Cabinet and land on the “PCS” Connection

6.5 Commissioning

6.5.1 Introduction

Commissioning of a newly installed and existing ESS that has been retrofitted, replaced or previously decommissioned and is returned to service shall be conducted prior to the ESS being placed in service in accordance with a commissioning plan that has been approved prior to initiating commissioning.

6.5.2 RPSLinkIN Commissioning Checklist

Commissioning Checklist – RPSLinkIN				
Phase	Step	Checklist Item	Status (OK / Pending / N/A)	Comments / Notes
Phase - 1 Pre-commissioning and Documentation Review	1.1	Verify design documentation set (single-line diagrams, layout, control logic, network diagram)		
	1.2	Confirm permits, interconnection approvals, and utility witness test plan readiness		
	1.3	Review as-built wiring vs drawings; mark deviations		
	1.4	Verify system labeling, nameplates, and warning signage		
	1.5	Safety documentation — lockout/tagout plan, emergency response plan		
	1.6	Verify quality QA/QC checks completed for RPSLinkIN and site-specific Infrastructure		
Phase - 2 Mechanical & Installation Inspection	2.1	Check physical mounting of components are level / sufficient		
	2.2	Confirm system is located away from physical obstructions and has adequate access for maintenance support		
	2.3	Inspect conduit entries and gland seals to be properly secured		
	2.5	Verify Electronic Box is secured		
Phase - 3 Electrical Verification (Before Energization)	3.1	ATS OPTION ONLY: Torque check on terminal block for utility connection to ATS (as per manufacturer specifications)		
	3.2	ATS OPTION ONLY: Torque check on terminal block for load connection to ATS (as per manufacturer spec)		
	3.3	Torque checks on Main Load Over Current Protection Device (OCPD) inside electronic box (as per manufacturer spec)		
	3.4	Torque check on Breaker connections for inverters x2 inside Electronic box (as per manufacturer spec). Load side and line side		
	3.5	Confirm system grounding/bonding continuity meets the NEC, verified by electrical contractor		
	3.6	Verify Over Current Protection Device (OCPD) reset/close and open without issues		
	3.7	Verify auxiliary power circuits (control, UPS, Network Switch, VCOM)		
	3.8	Verify all ethernet connections are made to drawing		
	3.9	Verify all grounds are secured on the RPS50 batteries		
	3.10	Verify all grounds are secured on the Power Skid		
Phase - 4 Controls, Communication & Software	4.1	Power up control system on auxiliary power only (no DC main contactors/disconnect closed)		
	4.2	Test communication links (VCOM ↔ HMI ↔ PCS)		
	4.3	Verify alarms and event logging functions		
	4.4	Verify VCOM antenna connections are correct and secured		
	4.5	Verify VCOM communication (LTE, WiFi or Ethernet connection)		

Commissioning Checklist – RPSLinkIN				
Phase	Step	Checklist Item	Status (OK / Pending / N/A)	Comments / Notes
<i>Phase - 5</i> Functional / Dry Run Tests	5.1	Close main contactors under electrical contractor or engineering supervision (initial DC energization)		
	5.2	Run charge/discharge command tests at low power (< 10%)		
	5.3	Verify SOC reporting accuracy, voltage/current sensor calibration		
	5.4	Confirm alarm triggers: To HMI and to ViSTA® system		
	5.5	Test emergency stop [E-STOP] and system safe shutdown sequence		
	5.6	Verify RPSLinkIN is visible and active on ViSTA® Monitoring Platform		
<i>Phase - 6</i> Performance / Integration Tests	6.1	Run charge/discharge command tests at low power capacity (< 10%)		
	6.2	Run charge/discharge command tests at mid power capacity (50%)		
	6.3	Run charge/discharge command tests at full power capacity (approx. 100%)		
	6.4	ATS OPTION ONLY: Run full load with utility present through ATS to load		
	6.5	ATS OPTION ONLY: Shutdown utility and verify switchover to battery support through PCS		
	6.6	ATS OPTION ONLY: Run full load with support on battery power only (no utility present)		
	6.7	ATS OPTION ONLY: Turn utility back on, verify ATS switches back to normal utility operation		
	6.8	ATS OPTION ONLY: Charge battery unit to top of charge with utility present and supporting the load, verify stops and idles at top of charge		
<i>Phase - 7</i> Final Acceptance and Documentation	7.1	Collect test data, sign-off sheets, torque records, calibration certificates		
	7.2	Train operations personnel on normal and emergency procedures		
	7.3	Submit commissioning report and punch-list closure		
	7.4	Provide as-built drawings and configuration backups as required		
	7.5	Transition to warranty/start of service period		

OPERATION



7. Startup

7.1 RPSLinkIN General Startup Instructions

1 — Apply Power to the Unit

Move the front selector switch to the “ON / Normal” position.

The DEIF IE250 should power on.

Verify that utility/grid power is present.

2 — Utility Hold-Up Behavior

If the correct AC utility voltage is present, the unit will remain powered even if the selector switch is returned to the “OFF” position.

Step 1 — Access WebVisu


- On the **front HMI (DEIF IE250)**, tap the **back arrow**, then select **“WebVisu.”**

Step 2 — Accept Connection

- Select **“Accept.”**


Step 3 — Verify Unit Mode

- Open the bottom menu and select **“Settings.”**




Step 4 — Select Operating Mode & Setpoints

- Choose the desired mode and configure the associated setpoints:
 1. **Time of Day**
Allows input of time-of-day schedule, SOC limits, and charge/discharge power setpoints.
 2. **Cycling**
Allows input of power setpoints. The unit automatically cycles from top of charge to bottom of charge repeatedly.
 3. **Manual Operation**
Allows direct power command input. The unit will charge or discharge according to the setpoint.
 4. **EMS - *Optional***
Non-configurable. Unit follows all commands from the external EMS.




Step 5 — Start the System

- On the **Overview** tab, select “Tap to Start.”



Step 6 — Verify Output

- Confirm the unit is producing the **desired power setpoint**.



7.2 RPSLinkIN Advanced Settings

Advanced Settings (Ramp Rate & Fan Mode)

Step 7 — Login for Advanced Configuration

To change ramp rate or fan mode:

- Select “Login.”
- **Username:** ADMIN
- **Password:** 1001

The screenshot displays the RPSLinkIN Advanced Settings interface. On the left, under the 'Settings' tab, there are four 'Enable Mode' toggle switches: 'Time Of Day Cycling Settings', 'Cycling Settings', 'Manual Operation Settings', and 'Energy Management System'. The 'Manual Operation Settings' toggle is currently turned on. On the right, under the 'Other Settings' tab, the 'Set Power Increase Rate (kW/sec)' is set to 6.0, with a slider below it ranging from 0 to 6. Below this is the 'Fan Control' section with an 'AUTO' button. On the far right, there are 'Login' and 'Logout' buttons, a 'User: Administrator' indicator, and buttons for 'Inverter/ATS Info', 'Battery Info', and 'Controller Info'. At the bottom, a navigation bar contains 'OVERVIEW', 'ALARMS', and 'SETTINGS' buttons. The version number 'Version:1.2.0.0' is displayed at the bottom right.

Step 8 — Verify Fan Mode


Fan Mode Options:

- **On:** Fan runs continuously.
- **Off:** Fan stays off.
- **Auto:** Fan turns on/off automatically as needed.

This screenshot is identical to the one above, showing the RPSLinkIN Advanced Settings interface. The 'Manual Operation Settings' toggle is turned on, and the 'Set Power Increase Rate (kW/sec)' is 6.0. The 'Fan Control' button is set to 'AUTO'. The interface includes navigation buttons for 'OVERVIEW', 'ALARMS', and 'SETTINGS', and a version indicator 'Version:1.2.0.0'.

Step 9 — Adjust Ramp Rate

- Use the ramp-rate slider to set the desired **kW/sec inverter ramp rate**.



8. SHUT DOWN

8.1 RPSLinkIN Shutdown Instructions

Step 1 — Stop the System

- On the **Overview** tab, select **“Tap to Stop.”**
- The system should cease power production, and the batteries will shut down.

Step 2 — Verify Utility Status

- Confirm that **no utility/grid power** is present before proceeding.

Step 3 — Turn Off the Main Switch

- On the front of the unit, toggle the main power switch to the **“OFF”** position.

MAINTENANCE

9. Maintenance

Note:

- Personnel performing maintenance on the RPSLinkIN must be trained and familiar with the operation and configuration of RPSLinkIN components.
- The BESS must be completely disconnected (external power source in a de-energized state with proper Lock Out – Tag Out [LOTO] devices installed) for all external connections and interfaces prior to any type of maintenance operation.
- Clearing and Cleaning - After installation and commissioning, regularly clean, check ventilation and air exhaust devices. Periodic cleaning is recommended, to start (based on environmental characteristics) a three-month schedule is recommended. After installation and commissioning, regular fan, filters and inspection time and systems checks may be extended at customer discretion.
- If torquing of fitting and/or connections are required, verify the torque wrench has a current calibration sticker.
- If any maintenance is performed that involves disturbing electrical connections, ensure that connections are re-torqued to specification afterwards.

9.1 Periodic Scheduled Maintenance

The following is a recommended scheduled maintenance check/verification for the internal/external components of the RPSLinkIN

Task List <i>(see 9.1.1 thru 9.1.5 below for item locations and detail)</i>	Commissioning	Monthly	Quarterly	Semi-Annually	Annually	As Indicated
9.1.1 Sinexcel Inverters - Vacuum all dust and debris from the unit			X			
9.1.1 Sinexcel Inverters - Using low pressure dry compressed air source, blow air through the mesh and fans			X			
9.1.2 PCS Cabinet - General inspection inside of the enclosure for contaminants and/or dust	X			X		
9.1.2 PCS Cabinet – preventative maintenance check for intake/exhaust filter and exhaust fan					X	
9.1.3 General Electrical and Bolt Interface Connections - Check for oil, dust, oxidation, and contaminant accumulation	X				X	
9.1.4 Energy Management System (EMS) Cabinet(s) <i>(optional accessory external to RPSLinkIN)</i> - Check for oil, dust, oxidation, and contaminants accumulating inside of the cabinet	X					X
9.1.5 Torque Check – Perform thermal check OR torque value check	X				X	

9.1.1 Sinexcel Inverter

General inspection of the Sinexcel inverters, mounting and electrical connections in accordance with the Sinexcel Operations manual (P/N: PWS2-30P-NA). General maintenance shall include but not be limited to:

- Vacuum all dust and debris from the unit
- Using a low pressure compressed air source, blow air through the mesh and fans

Note that the Sinexcel manual suggests quarterly general maintenance but based on the container being sealed and well-ventilated these can be reduced to annual checks, so long as the container doors are not left open for extended periods of time.

9.1.2 PCS Cabinet

General inspection inside of the enclosure for contaminants and/or dust. Intake filter and exhaust fan cleaned by specification sheet. General maintenance shall include but not be limited to:

- Exhaust Fan (Viridi P/N: 2410-00029, MFG P/N: 11632804055)
- Exhaust Filter (P/N: 1000-00151, MFG P/N: 18611600035)
- Clean inside of cabinet with low pressure compressed air, visually inspect fan blades.

9.1.3 General Electrical and Bolt Interface Connections

Check for oil, dust, oxidation, and contaminants accumulating on or around electrical components

- If oil, dust or contaminants are found on or around electrical components, use low pressure air and a clean microfiber cloth to clean connections
- If oxidation is found on or around electrical components, contact Viridi customer service for oxidation removal procedure.

9.1.4 Energy Management System (EMS) Cabinet(s)

Energy Management System (EMS) is an optional cabinet or cabinets external to the RPSLinkIN components

Check for oil, dust, and contaminants accumulating inside of the cabinet

- If oil, dust or contaminants are found on or around electrical components, use low pressure air and a clean microfiber cloth to clean connections
- If oxidation is found on or around electrical components, contact Viridi customer service for oxidation removal procedure.

9.1.5 Torque Check


Check proper torque for all identified electrical connections. Torque checks can be performed by thermal imaging OR torque mark visual OR torque value checks.

- **Thermal Imaging Check** – perform thermal imaging procedure with unit in operation. Compare with the thermal imaging control provided by Viridi to determine hot spots. If hot spots are located, check torque with proper torque wrench after following disconnect and LOTO procedures. Note: Thermal imaging procedure and control may not be available initially. Viridi to provide information once procedure and control are established.
- **Torque Mark Visual Check** – Any fasteners that have a clear torque mark indicator (paint pen running across fastener head onto electrical component) can be visually inspected to ensure there is no break in the torque mark indicator between the fastener and component. Note: not all fasteners will have torque mark indicators and will need to be checked with thermal imaging or torque value checks.
- **Torque Value Check** – Use a calibrated torque wrench to manually check each electrical connection's torque value in accordance with the torque values provided in the table below and the corresponding figures/locations

9.1.6 Torque Check Table

Component	Location(s)	Torque Value [Nm]	Frequency
100A Main Breaker	[A]	9Nm	Annually
50A Inverter Breakers (1 or 2)	[A]	9Nm	Annually
3 Pole Distribution block	[B]	12.5Nm	Annually
1 Pole Distribution block GND	[B]	12.5Nm	Annually
Inverter 3phase connection (1 or 2)	[B]	5.1Nm	Annually
PWD-100M Intelligent Switch Module (Optional)	[C]	20Nm	Annually




Warning



Verify All External Power Is OFF and Switches Are in the OFF Position

9.1.7 Torque Reference Images

The following identifies the specific location and image description of the components requiring torque checks

Location (description)	Image
Location A – Electronics Box. 1 – 100Amp Breaker 2 – 50Amp Breaker	
Location B – Power Skid 3 – 3 Pole distribution block 4 – 1 Pole distribution block 5 – Inverter 3 phase connection	
Location C – Intelligent Switch module location (Optional)	

9.2 Decommissioning

- Contact Viridi first
 - Perform one final physical inspection.
 - Lower SOC to 30% SOC.
 - Go through a shutdown procedure (Reference Section 8.1 Shut Down Instructions)
 - Disconnect all exterior/customer connections (Utility connection, ethernet, CANBUS, Fiber connection, etc..).
 - Plug / Seal any holes left in the customer connection panel
 - Open all Breakers in the Electronics Box
 - Visually Validate everything in the unit is powered off
 - The local AHJ shall be notified prior to decommissioning

9.3 ViSTA® Alarm Definition Glossary

Severity	Description	High Level Definition
Critical	High Impact to Functionality	Anything that can cause the unit, or the "Grid" to shut down Ex. E-stop pressed
	Requires Immediate Attention	
Major	High Impact to Functionality	Anything that can cause a skid to go down or a major component to go down. Ex. Inverter alarms or battery DTC alarms
	May not require attention right away	
Warning	Does not impact functionality but if this continues it could cause an alarm	Does not impact on the overall functionality but if this state continues, it will lead to an alarm (either minor, and/or major).

9.4 ViSTA® Alarms

Here are some of the common ViSTA® alarms, their severity, and a brief explanation along with the action needed to resolve them.

Alarm Name	Severity	Triggered By	Description / Take Action
E-STOP Activated	CRITICAL	E-STOP	Emergency Stop pressed. Disengage E-Stop and Power Cycle BESS.
EMS Communication Lost (Optional)	MAJOR	HMI	RPSLINK to Viridi Energy Management System lost. Contact Viridi Customer Service.
ViSTA® Connection Lost to Asset	MAJOR	ViSTA® Cloud	Communications failure between VCom and ViSTA® Cloud. Check wired internet connection (if applicable) and LTE coverage. If an error persists, call Viridi Customer Service.
String "X" BMS Temperature Warning	MAJOR	String "X" BMS	BMS on String X senses battery cell temperature too high. Ensure fan filters are clear and BESS is ventilating properly.
String "X" BMS Temperature High Error	MAJOR	String "X" BMS	BMS on String X senses battery cell temperature too high. Ensure fan filters are clear, and BESS is ventilating properly.
String "X" Inverter AC Bus Over Voltage	MAJOR	String "X" Inverter	Inverter on String X senses AC voltage is too high. Check source voltage (can be done through the Deif HMI or ViSTA®). If an error persists, call customer service.
String "X" Inverter AC Bus Under Voltage	MAJOR	String "X" Inverter	Inverter on String X senses AC voltage is too low. Check source voltage (can be done through the Deif HMI or ViSTA®). If an error persists, call customer service.
String "X" Inverter AC Bus Over Frequency	MAJOR	String "X" Inverter	Inverter on String X senses AC frequency is above conformance. Check frequency (can be done through the Deif HMI or ViSTA®). If an error persists, call customer service.
String "X" Inverter AC Bus Under Frequency	MAJOR	String "X" Inverter	Inverter on String X senses AC frequency is below conformance. Check frequency (can be done through the Deif HMI or ViSTA®). If an error persists, call customer service.
String "X" Inverter AC Bus Phase Reversed	MAJOR	String "X" Inverter	Inverter on String X senses AC phase (L1, L2, L3) are incorrect orientation. Check AC wiring to BESS.
String "X" Inverter AC Bus Voltage Asymmetric	MAJOR	String "X" Inverter	Inverter on String X senses AC voltage asymmetry. Check source voltage (can be done through the Deif HMI or ViSTA®). If an error persists, call customer service.
String "X" Inverter AC Bus Voltage Abnormal	MAJOR	String "X" Inverter	The inverter on String X senses AC voltage that is too high or too low for operation. Check source voltage (can be done through the Deif HMI or ViSTA®). If an error persists, call customer service.
String "X" Inverter AC Bus Phase Lost	MAJOR	String "X" Inverter	The inverter on String X does not sense AC power. Ensure BESS is in the correct operational mode and that String level and system level breakers and contactors are closed. If an error persists, call customer service.
String "X" Inverter AC Overload Timeout	MAJOR	String "X" Inverter	Inverter on String X overload timeout. Load exceeded rated value; code will clear once load is under limit for 5 minutes. If an error persists, call customer service.
String "X" Inverter High Temperature Warning	MAJOR	String "X" Inverter	Inverter on String X senses internal temperature at AC or DC radiator too high. Ensure fan filters are clear, and BESS is ventilating properly.
String "X" Inverter High Temperature Error	MAJOR	String "X" Inverter	Inverter on String X senses internal temperature at AC or DC radiator too high. String offline. Ensure fan filters are clear, and BESS is ventilating properly. String will not function until inverter temperature drops to a safe threshold.
String "X" Inverter High Ambient Temperature Warning	MAJOR	String "X" Inverter	Inverter on String X senses ambient temperature too high. Ensure fan filters are clear, and BESS is ventilating properly.

Alarm Name	Severity	Triggered By	Description / Take Action
String "X" Inverter High Ambient Temperature Error	MAJOR	String "X" Inverter	Inverter on String X senses ambient temperature too high. String offline. Ensure fan filters are clear, and BESS is ventilating properly. String will not function until inverter temperature drops to a safe threshold.
String "X" Discharge Limit Enforcement Fault	MAJOR	String "X" PLC	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Charger Safety Relay Fault	MAJOR	String "X" PLC	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Internal Hardware Fault	MAJOR	String "X" PLC	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Internal Heatsink Thermistor Fault	MAJOR	String "X" PLC	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Internal Software Fault	MAJOR	String "X" PLC	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Highest Cell Voltage Too High Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Lowest Cell Voltage Too Low Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Pack Too Hot Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" High Voltage Interlock Signal Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Pre-charge Circuit Malfunction	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Abnormal State of Charge Behavior	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Internal Communication Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Cell Balancing Stuck Off Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Weak Cell Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting

Alarm Name	Severity	Triggered By	Description / Take Action
String "X" Low Cell Voltage Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Open Wiring Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Current Sensor Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Highest Cell Voltage Over 5V Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Cell ASIC Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Weak Pack Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Fan Monitor Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Thermistor Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" External Communication Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Redundant Power Supply Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" High Voltage Isolation Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Input Power Supply Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Charge Limit Enforcement Fault	MAJOR	String "X" BMS	Error code generated by RPS50 Battery Management System [Orion BMS2]. Call Viridi Customer Service. For error code definitions visit https://www.orionbms.com/troubleshooting
String "X" Max Charge Reached	Warning	HMI	Notification that Strings "x" hit the max charge. No action is needed.
String "X" Max Discharge Reached	Warning	HMI	Notification that Strings "x" hit the max discharge. No action is needed.

Additional Alarms with Optional Intelligent Switching Device

Alarm Name	Severity	Triggered By	Description / Take Action
ATS Fault System Fault (Optional)	CRITICAL	HMI	ATS system fault. Please Contact Customer Service.
ATS Fault System Failure (Optional)	CRITICAL	HMI	ATS system failure. Please Contact Customer Service.
ATS Load Overload Timeout (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Load Overload Alarm (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Load Neutral Overcurrent (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Load Voltage Abnormal (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Load Phase Reversed (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Force Bypass (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Galvanic Break Short (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Galvanic Break Open (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Synchronization Failed (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Frequent Switching Fault (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Overload Timeout (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Overload Alarm (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Neutral Overcurrent (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Connection Forbidden (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Power Down (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Neutral Lost (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Phase Lost (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Voltage Abnormal (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Voltage Asymmetric (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Phase Reversed (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.

Alarm Name	Severity	Triggered By	Description / Take Action
ATS Grid Under Frequency (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Over Frequency (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Under Voltage (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.
ATS Grid Over Voltage (Optional)	MAJOR	HMI	ATS has an alarm. Please contact customer service.

9.5 Contact Viridi Customer Service

If an issue is identified with the RPSLinkIN, please contact Viridi Customer Support at 1-866-984-7434

The following information will be requested:

Company Name	
Contact Name and Call Back #:	
Serial Number:	
Set Up Details:	
Fault Details, including history relevant to the fault:	